

## Vaisala Ultrasonic Wind Sensor WMT700



ĺ	WMT 7 0	T					I							
1	Measurement range	.1	1											1
	40 m/s WMT701	1												
	40 m/s + Accredited Wind Calibration (WMT701)	Α												
2	Temperature range -10+60 C		٨											
	-10+60 C -40+60 C		A B											
	-55+70 C		C											
3	Heating			ı										
	Non-heated version			1										
	Heated transducers			2										
	Heated transducers and arms			3										
4	Heated transducers, arms and body  Digital communication interface			4	J									
4	RS-485 isolated				Α									
	RS-422 isolated				В									
	RS-232 isolated				С									
	SDI-12 isolated				D									
5	Digital communication profile	9600b, 8, N, 1 Pol	llod			0								
	WMT70 - poll mode (default) WS425 - ASCII	2400b, 8, N, 1 Pol				1								
	WS425 - NMEA Extended (v 0183)	9600b, 8, N, 1 Aut				2								
	WS425 - SDI-12 (v 1.3)	1200b, 7, E, 1 Pol				3								
	WS425 - ASOS	2400b, 8, N, 1 Pol	lled			4								
	ROSA - MES12	9600b, 8, N, 1 Pol				5								
6	AWS520 - NMEA Extended (v 0183)	4800b, 8, N, 1 Aut	to send 1/s			8	J							
O	Digital communication units m/s						Α							
	knots						В							
	mph						С							
	km/h						D							
7	Analog output signals for wind speed channel							0						
	Disabled Voltage output	100 mV/m/s						0 1						
	Current output	420 mA	(0Range	m/s)				3						
	Current output	0.2 mA/m/s	(o tarigo					4						
	Push-Pull frequency output	10 Hz/m/s						6						
	WS425 - voltage output	8 mV/mph						7						
	WS425 - frequency output (Push-Pull)	5 Hz/mph						8						
	Pull up frequency output (PNP) Pull down frequency output (NPN)	10 Hz/m/s 10 Hz/m/s						A B						
8	Analog output signals for wind direction channel	10 112/11/5												
_	Disabled								0					
	Voltage output	20 mV/Deg							Α					
	Current output	50 uA/Deg							D					
	Current output 420 mA Potentiometer output (WS425)	44.444 uA/Deg 0Vref (Vref = ext	tornal refere	nee veltees	from oveter	m\			E F					
9	Cable	Oviei (viei – ex	terrial refere	rice voitage	i iioiii systei	111)								
Ü	None									1				
	Cable 2 m, cable connector, open leads on one e									2				
	Cable 10 m, cable connector, open leads on one	end								3				
	MAWS cable 10 m									4 5				
	AWS520 cable 10 m, shield connected to PE pin Adapter cable for WS425 serial									6				
	Adapter cable for WS425 analog frequency output	ıt								7				
	RS485 Cable 2 m, cable connector, open leads o	n one end								8				
	RS485 Cable 10 m, cable connector, open leads	on one end								9				
	Adapter cable for WS425 analog voltage output	nin								A				
	AWS520 cable 10 m, shield not connected to PE ROSA analog cable 10 m, cable connector, open									B C				
	Junction Box with Cable 2meters									D				
	Cable 15 m, cable connector, open leads on one									E				
, -	Cable 26 m, cable connector, open leads on one									F				
10	Mounting adapter				Ctandard -	donto '	fiv							
	Adapter 228869 only Adapter 228869 with WMT70FIX70 (suitable also	for inverted mounti	na)		Standard a		fix general pur	nose fiv			A B			
	Adapter 228869 with WMT70FIX70 (suitable also Adapter 228869 with WMT700FIX60-POM	ioi inveneu moundi	19)				plastic fix for		ole		Č			
	Adapter 228869 with WMT700FIX60-RST				Standard a	dapter with	stainless st	eel fix for 6			D			
	Adapter 228777 only (used for old WS425 FIX30)	60)					lapter, no fix		-		E	j		
11	Power - Reserved for furture purposes													
12	None Accessories											7	j	
12	None												Α	
	Bird cage												В	
13	Manual	<del></del> _			-						· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·		
	None English													1 2
														4
														3
	Japanese Chinese													3 4
	Japanese													

For freezing conditions select appropriate combination of heating and temperature ranges.

Verifier Cable Tightener Tool	WMT70Verifier 237888SP
Bird cage Bird perch	WMT70BirdKit WS425BirdPerch
Cable connector Cable 2 m, cable connector, open leads on one end Cable 10 m, cable connector, open leads on one end Cable 15 m, cable connector, open leads on one end Cable 26 m, cable connector, open leads on one end RS485 Cable 2 m, cable connector, open leads on one end RS485 Cable 10 m, cable connector, open leads on one end RS485 Cable 10 m, shield connected to PE pin AWS520 cable 10 m, shield connected to PE pin AWS520 cable 10 m, shield not connected to PE pin ROSA analog cable 10 m, cable connector, open leads on one end Adapter cable for WS425 serial Adapter cable for WS425 analog frequency output Adapter cable for WS425 analog voltage output Junction Box with Cable 2meters	WMT70Conn 227567SP 227568SP 237890SP 237889SP 228259SP 228250SP 227566SP 229807SP 227566SP 231425SP 227569SP 227570SP 227571SP ASM210719SP
MMT700 Mounting Accessories: Adapter for FIX70 Fix70 (suitable also for inverted mounting) Mounting adapter 60mm POM Mounting adapter 60mm RST Cross-arm (40x40x850mm)  WS425 Mounting Accessories: Adapter for old WS425 FIX30/60 FIX30 FIX60 Sensor support arm for 60mm pole (655mm with integrated fix for item 228777)	228869 WMT70FixSP WMT70FIX60-POM WMT700FIX60-RST WMT70CROSSARM  228777 WS425Fix30 WS425Fix60 WAC425
	Cable Tightener Tool  Bird cage Bird perch  Cable connector Cable 2 m, cable connector, open leads on one end Cable 10 m, cable connector, open leads on one end Cable 15 m, cable connector, open leads on one end Cable 26 m, cable connector, open leads on one end RS485 Cable 2 m, cable connector, open leads on one end RS485 Cable 10 m, cable connector, open leads on one end MAWS cable 10 m, shield connected to PE pin AWS520 cable 10 m, shield not connected to PE pin ROSA analog cable 10 m, cable connector, open leads on one end Adapter cable for WS425 serial Adapter cable for WS425 analog frequency output Adapter cable for WS425 analog voltage output Junction Box with Cable 2meters  WMT700 Mounting Accessories: Adapter for FIX70 Fix70 (suitable also for inverted mounting) Mounting adapter 60mm POM Mounting adapter 60mm RST Cross-arm (40x40x850mm)  WS425 Mounting Accessories: Adapter for old WS425 FIX30/60 FIX30 FIX60